



DETAIL C
SCALE 2 : 1.5

NOTES

ADJUSTING THE ACTUATING ARM USING
THE HB-AAA TOOL

TOLERANCES:

DECIMAL: $\pm .005$
FRACTIONAL: $\pm .015$
ANGULAR: $\pm 2^\circ$

(EXCEPT AS NOTED)
MATERIAL:

SCALE:
2:3

DATE:

09/01/15

REVISION:

REVISION DATE:

SHEET:
1 of 1



5301 SAWYER AVENUE BOISE, ID 83714
Phone: (208) 375-5000 www.hydroblend.com

DESCRIPTION:

ACTUATING ARM
ADJUSTMENT